ZDB: THE IMPEDANCE AT A DISTRIBUTION BOARD

NO SUB-BOARD. WHAT GOES IN ZDB?

Z_{db} is the loop impedance measured at a distribution board. And it behaves the opposite way to Z_e:

> `No disconnection. You want the parallel paths.`

Your leads go straight onto the earth bar and up to the main switch. Nothing comes off.

> ✋ **You cannot leave Z_{db} blank on the schedule.** It asks for a value and it needs one. If there is no secondary board, **enter your Z_e value** — with a Z_e of 1.09 Ω, that same 1.09 Ω is written in both places.

Free section from Sparky Study Notes. The full Level 3 notes, 1,463 practice questions and the video lessons: sparkystudynotes.co.uk